

Пример настройки сканера Symbol LS2208 для работы с SIC e8/e9/e10 (занесение ШК в переменную BCR)



SET DEFAULTS



Begin New Rule



Send Control B



Send Control 2



Send Control E



Send B



Send C



Send R



Send =



**Send All Data That Re-
mains**



Send Control C



Save Rule